Monitoring relays - ENYA series

- ► Voltage monitoring in 3-phase mains in accordance with <u>VDE 0126-1-1</u>
- Quick net error recognition
- Supply voltage = measured voltage
- 2 change over contacts
- Width 35mm
- Installation design



Technical data

■ 1. Functions

Voltage monitoring in 3-phase mains in accordance with VDE 0126-1-1 with fixed tripping delay, fixed threshold, adjustable 10-minutes-average and selectable fault latch by means of rotary switch.

WIN Monitoring the fixed adjusted range

WIN+Latch Monitoring the fixed adjusted range with fault latch

2. Time ranges

Adjustment range
Tripping delay (ON-Delay): fixed, 30s
Switch-off delay:

U ≤ 80% of U₂ < 200ms

 $U \le 80\%$ of U_N < 200ms $U \ge 115\%$ of U_N < 200ms phase failure < 20ms

3. Indicators

Green LED ON/OFF: indication of supply voltage Yellow LED ON/OFF: indication of relay output

■ 4. Mechanical design

Self-extinguishing plastic housing, IP rating IP40 Mounted on DIN rail TS 35 according to EN 50022

Mounting position: any

Shockproof terminal connection according to VBG 4 (PZ1 required),

IP rating IP20

Tightening torque: max. 1Nm

Terminals capacity:

1 x 0.5 to 2.5mm² with/without multicore cable end

1 x 4mm² without multicore cable end

2 x 0.5 to 1.5mm 2 with/without multicore cable end 2 x 2.5mm 2 flexible without multicore cable end

► 5. Input circuit

Supply voltage: (= measured voltage)
Terminals: (N)-L1-L2-L3

Rated voltage Un: see table ordering information or

printing on the unit
Tolerance: -30% to +30% of Un
Rated consumption: 11VA (1,2W)
Rated frequency: AC 48 to 63Hz
Duty cycle: 100%

Duty cycle: 100%
Reset time: 500ms
Hold-up time: -

Drop-out voltage: determined by measuring function

(see measuring circuit)

Overvoltage category: III (in accordance with IEC 60664-1)

Rated surge voltage: 4kV

6. Output circuit

2 potential free change over contacts Rated voltage: 250V AC

Switching capacity: 1250VA AC1 B300/P300

(in accordance with IEC 60947-5-1)

therm. constant current 5A

Fusing: 5A fast acting

Switching frequency: max. 6/min at 1000VA resistive load

(in accordance with IEC 60947-5-1)
Overvoltage category: III. (in accordance with IEC 60664-1)
Rated surge voltage: 4kV

▼ 7. Measuring circuit

Measured variable: 3(N)~, sinus, 48 to 63Hz
Measured input: (= supply voltage)
Terminals: (N)-L1-L2-L3
Overload capacity: determined by tolerance

specified for supply voltage

Input resistance:

Switching threshold Us: see table ordering information or

printing on the unit

10-minutes-average: see table ordering information or

printing on the unit

Overvoltage category: III (in accordance with IEC 60664-1)

Rated surge voltage: 4kV

8. Accuracy

Base accuracy: <2%
Adjustment accuracy: Repetition accuracy: ≤1%
Voltage influence: -

Temperature influence: ≤0,05% / °C

9. Ambient conditions

Ambient temperature: -25 to +55°C
Storage temperature: -25 to +70°C
Transport temperature: -25 to +70°C
Relative humidity: 15% to 85%

(in accordance with IEC 60721-3-3

class 3K3)

Pollution degree: 2, if built in 3

(in accordance with IEC 60664-1)


10. Weight

Single packing: 94g

Functions

Window function WIN:

When the supply voltage U is applied, the output relay R switches into on-position after the set interval of the tripping delay (ON-Delay) has expired and if the measured voltage is within the fixed adjusted window. When the measured voltage leaves the window between the fixed adjusted range, the output relay R switches into off-position If the voltage reenter the adjusted window, the output relay R switches into on-position after the set interval of the tripping delay (ON-Delay) has expired.




10-minute-average

The 10-minute average functions as a monitoring of the voltage quality. A floating average over 10 minutes will be measured at each input voltage. The output relay R switches into off if the floating average is exceeded.


WIN+Latch:


When the supply voltage U is applied, the output relay R <u>doesn't switch</u> into on-position indepentend of the measured voltage!

The fault latch must be deactivated (turn the function selection switch to the left = Latch OFF), so that the output relay switches into on-position. When the measured voltage is within the fixed adjusted window, the output relay R switches into on-position after the set interval of the tripping delay (ON-Delay) has expired. As soon as the output relay R is into on-position, the fault latch can be activated (turn the function selection switch to the right = Latch ON). Now the unit is in the monitoring mode with restart lockout.




Connections





Dimensions



Ordering information

Туре	Rated voltage U _N	Switching threshold U _S		10-minutes-average	Part Nr. (PQ 1)
E3YF400VFAL02	3(N)~400/230V	fixed 0,8 x U _N fixed 1,15 x U _N	,	1,1 x U _N to 1,15 x U _N (253V to 264V)	1341400

